


*NC = DO NOT CONNECT

*RST connection to CAN IMU is optional:
in FW we have software reset

TITLE: SCHA63T-K03		REV: 1.0
EasyEDA	Company: Basecamelectronics	Sheet: 1/1
	Date: 2021-08-10 Drawn By: signx	